


- Quick, safe and easy to install
- Perforated to allow the transmission of water vapor
- Reduces heat loss and heat gain all year round
- Can block up to 96% of radiant heat transfer

INSTALLATION METHOD #1 - Bottom of Rafters

1. Always exercise caution when working on insecure floors - place a board on the attic floor to stand on during installation.
2. The radiant barrier will be installed on the underside of the rafters with the material being run across the rafter facings (Figure 1).
3. Affix the radiant barrier to the underside of the rafters using regular staples, 6" apart. Be sure to leave a 6" gap on either side of the ridge vent, to ensure adequate ventilation.



Figure 2



ECOFOIL REFLECTIVE INSULATION > **EF4800-48-125P (500 square feet)**
ECOFOIL REFLECTIVE INSULATION > **EF4800-48-250P (1,000 square feet)**

Check local building codes for compliance before installation. This installation sheet is intended solely to illustrate the proper location and placement of EcoFoil® Reflective Insulation products in specific construction applications. They are not intended to illustrate proper construction methods (which is ultimately the responsibility of the builder or contractor). The installation instructions are only recommendations relating to the location and placement of EcoFoil® Reflective Insulation products, and EcoFoil® makes no claims that these construction systems are universally accurate.

All warranties and performance estimates are void if EcoFoil® Reflective Insulation products are used in exterior applications, or in non-enclosed systems or buildings.

Exercise caution when using EcoFoil® Reflective Insulation products near and around electrical wiring and devices.