


- Ideal insulation for post frame building applications
- Quick and easy to install, while adding R-value
- Reduces heat loss and heat gain all year round
- Can block up to 97% of radiant heat transfer

INSTALLATION METHOD

1. If Trusses or wall posts are 48" or greater on center, add wood furring strips in the 'cross' direction to wall posts and roof trusses.
2. Unroll EcoFoil® insulation horizontally - in the direction of the furring strips - and staple into place.
3. To ensure a continuous insulation system, seal all seams and butt joints with EcoFoil® tape.

Builder's Notes:

- If a white interior finish is desired, EcoFoil® poly reflective insulation may be used. Install as per usual method, however with poly-white side facing interior.
- Use EcoFoil® white poly tape to seal all seams and butt joints.
- When EcoFoil® insulation comes in direct contact with ACQ lumber, it may discolour. This will not affect the overall insulation value of EcoFoil® insulation.



SUGGESTED PRODUCTS FOR THIS APPLICATION:

- | | |
|--------------------------|---|
| REFLECTIVE INSULATION | › 2200, 2500, 6272 or 6273 series - available in various dimensions |
| EcoFoil® REFLECTIVE TAPE | › 15213 (reflective), 15853 (white poly) |

Check local building codes for compliance before installation. This installation sheet is intended solely to illustrate the proper location and placement of EcoFoil® Reflective Insulation products in specific construction applications. They are not intended to illustrate proper construction methods (which is ultimately the responsibility of the builder or contractor). The installation instructions are only recommendations relating to the location and placement of EcoFoil® Reflective Insulation products, and EcoFoil® makes no claims that these construction systems are universally accurate.

All warranties and performance estimates are void if EcoFoil® Reflective Insulation products are used in exterior applications, or in non-enclosed systems or buildings.

Exercise caution when using EcoFoil® Reflective Insulation products near and around electrical wiring and devices.